


**SELCO**



# SELCO D1000 Arc Protection Installation and Configuration Guidelines

# Wind Turbines without Arc Fault Protection

**SELCO**



These wind turbines could have been saved by an Arc Fault Protection system like the D1000. Arc Fault Protection cannot prevent failure, but it will restrict the damage so that the installation can be easily repaired.

... just imagine what it will take to repair those wind turbines (in the middle of the ocean)!

# Arc Faults – Dangerous and Costly!

**SELCO**




May lead to fires, burns, unrepairable damage - and **loss of life...**



## The Effects of an Arc Fault

**SELCO**




Unrepairable damage to equipment – Risk of serious personal injury to personnel

# Arc Development

**SELCO**

When overvoltages of sufficient amplitude enter the switchboard from either the consumer side or the power supply side, several subsequent steps occur to form the final flashover (Arc).



In the example below, a simple cross sectional drawing of a copper busbar in a switchboard is used. The flashover (Arc) will develop between the corner of the busbar and the bolt head at the side of the cabinet.





# The 6 Steps of the Arc Lifespan

**SELCO**



1.





2.





3.





4.




5.



6.




# D1000 Dimensions



Depth (including plug-in terminals): 52 mm.

## D1000 DIN rail mounting


**SELCO**



Optional green DIN-rail snap-on brackets available (increases depth approximately 11 mm. – including DIN rail)




# D1000 Connection Terminals



Relays are shown with D1000 in online state (normal operation)

# Typical Switchboard Application with two modules linked as one system


**SELCO**



System can be expanded with even more D1000 modules

# D1000 PC Based Configuration

# SELCO



**SELCO Configuration tool**

**Configure General parameters**

This Unit  
Description of this unit, e.g. placement:

Date and time  
Update the internal clock from the PC time: ☐

All rights reserved Selco A.S. Copyright (c) 2009.

**Configure Current sensor**

Setting

Enable inhibit if current is below a level: ☐

Enable trips on overvoltage: ☐

Enable trips on short: ☐

Full scale current: 5000 ampere (CT secondary)

Limits and time delays

Indication blink when above: 100 Percent of full scale current

Inhibit function above trip above: 100 Percent of full scale current

Overload protection trip at probe above: 100 Percent of full scale current

**Configure Light sensors**

Light sensor 1:

Light sensor 2:

Light sensor 3:

Light sensor 4:

Light sensor 5:

Light sensor 6:

Light sensor 7:

Light sensor 8:

Light sensor 9:

Light sensor 10:

Light sensor 11:

Light sensor 12:

**Configure Trip output**

IGBT output

Trip switch type: Underlapage coil (Active when off)

Hold time before reset: 2 seconds

Order fall if IGBT switch is improved: ☐

All rights reserved Selco A.S. Copyright (c) 2009.

**Internal drives**

Reset configuration to factory default: ☐

Internal drives

Reset configuration drive to factory default: ☐

Reset log drive to factory default: ☐

All rights reserved Selco A.S. Copyright (c) 2009.

**Debug info**

Debug info

SELCO -> Your D1000 SERIES II is currently running a debug build!!!

SELCO: Generation took 224 ms

SELCO: SPN Revision: 11

SELCO: Number of parameters: 60

All rights reserved Selco A.S. Copyright (c) 2009.

- USB connection
- No driver installation is required on the PC
- PC configuration software is inside the D1000
- Runs on MS Windows®
- Easy firmware upgrade



# D1000 Supported Sensors

# SELCO



A1000 Point sensor

- 180 x 180° viewing angle
- LED for visual feedback
- Built-in circuit check
- 10 m. shielded cable
- Plug-in connector
- Non-epoxy material

**NEW!**



A2000 Fiber line sensor

- 8 m flexible fiber
- 360° viewing angle
- LED for visual feedback
- Built-in circuit check
- Electrically extendable
- Plug-in connector

**NEW!**





Existing SELCO A0200 / A0300 point sensors are supported  
(without support for circuit check)



# A1000 Point Sensor

**SELCO**



D1000 can also be used with existing A0200 / A0300 point sensors (without circuit check)


# A1000 Point Sensor Installation

**SELCO**



1. Place the included adhesive drill guide where you want the sensor to be mounted.
2. Mark and drill 2 of the 4 holes directly through the drill guide (depending on how the sensor is to be installed).

3. Fasten the sensor using pop rivets or self-tapping screws.



The sensor can also be mounted "see-through" from the back of the cabinet.



# A0200 / A0300 Point Sensor (old type)


**SELCO**

Easy upgrade...



## A0200 / A0300 Point Sensors




- Two wire connection
- No circuit check
- No visual feedback
- Mounting bracket needed for fixation



Mix of A1000, A0200 and A0300 Point Sensors

# Confirmation of installed sensors






1. Press  to switch to SERVICE mode (SERVICE LED will ignite)
2. Press and hold  to start the test sequence
3. All sensors and indicators will flash for about 10 seconds while the system tests all sensors
4. Observe that the TEST LED is flashing. Move a light source towards the TEST sensor until the LED turns off. Note the distance.
5. Observe that all connected sensors have now started flashing. Move a light source towards the sensors until they turn off.
6. When all sensors have been tested, the system will flash green on all sensors briefly, and go back to normal SERVICE mode.
7. Press  to switch back to ONLINE mode. The sensors are now configured, and the system will alarm if a sensor malfunctions.



# Performing a Simple Sensor Test






1. Press  to switch to SERVICE mode (SERVICE LED will ignite with steady red light)
2. Confirm that all indicators at connected sensors are showing a steady green light
3. Confirm that all connected sensors are giving a double flash of red light periodically, indicating that the sensor is being tested
4. Point a light source at a sensor and check that both the sensor LED and the indicator LED changes to steady blinking, and that the Tripped indicator turns on.
5. Repeat step 4 for the remaining sensors
6. Press  to switch back to ONLINE mode (ONLINE LED will ignite with steady green light)

Press  at any time to cancel test



# Testing the Trip Coil



1. Make sure that the system is ready for test (TRIP COIL output will be tripped during this procedure)
2. Press  to switch to SERVICE mode (SERVICE LED will ignite with steady red light)
3. Press  and hold it pressed for a few seconds to activate the TRIP COIL output
4. Observe that the connected trip coil trips correctly. The output will reset itself after the configured time, typically 2 seconds
5. Re-prime the TRIP COIL
6. Press  to switch back to ONLINE mode (ONLINE LED will ignite with steady green light)

# Full operations test (online)




1. Make sure that the system is ready for test (TRIP COIL output will be tripped during this procedure)
2. Press  to switch to ONLINE mode (ONLINE LED will ignite with steady green light)
3. Confirm that there is a steady green light in the sensor LED of each connected sensor (shows that sensors are connected and healthy)
4. Confirm that a short red flashing light occurs periodically in each detector (indicates that the sensor circuit is being checked)
5. Move a light source towards the TEST sensor and confirm that it starts flashing
6. Move the light source towards a sensor. Stop when the sensor LED start flashing with a green light (shows pre-warning before trip)
7. Now move light source closer to the sensor. Confirm that the TRIP COIL output trips and that the LEDs of the TRIP COILs sensor and detector changes to a flashing red light (trip)
8. Re-prime the TRIP COIL relay and press  to re-enable the system
9. Repeat steps 6 to 8 for the remaining sensors

# Adjustment of Sensor Sensitivity



1. Look up the proper adjustment level in the manual. You will need to know the power of the smallest arc fault you wish to detect, and the maximum distance from the sensors to a possible arc fault.

2. Adjust  to the corresponding trip level setting – lower numbers for smaller arcs and greater distances

TRIP LEVEL

3. If you have access to a calibrated light source, this can be used to check the trip level. Otherwise, a normal photo blitz can be used to check operation in service- or online mode. The output of a compact camera flash is approximately equivalent to a small arc fault, and should be detectable from all corners of the cabinet.




# D1000 Optional 3-phase Overcurrent Trip

# SELCO

Trips in less than 1 millisecond for short- and overcurrent protection.

Optionally inhibits tripping if the current is below a set level, still with less than 1 ms delay.





PC/USB based Configuration

# D1000 Trip Coil



Trip relay can be driven by external DC or AC voltage, by the supply voltage of the D1000, or by a chargeable 24 VDC battery.

Multiple D1000 units can be installed to control the same trip relay, by utilizing the Link feature.



PC/USB based Configuration

Undervoltage Trip: Trip Coil output trips by disconnecting the voltage to the trip relay

Shunt Trip: Trip Coil output trips by providing voltage to the coil of the trip relay Auto Release ensures that the relay coil is not stressed or damaged.

# D1000 Inputs and Relays

**SELCO**

## Inputs (NO, negative reference)


- INHIBIT:** Prevents activation of trip coil when one of the two inputs are active.
- TRIP:** Performs external trip of trip coil upon activation of one of the two inputs.
- RESET:** Performs external Reset of trip upon activation of one of the two inputs.

## Relay (NE, change-over / contact)

- ONLINE:** Indicates that D1000 is on-line. The online relay is also used to signal alarm conditions (with intermediate pulse for every new alarm)


## Relay (ND, change-over / contact)

- SERVICE:** Indicates that the D1000 is in service mode (off line).
- TRIPPED:** Indicates that the D1000 Trip Coil has been activated.



# D1000 Supply Module and Trip Coil driven by DC Supply

**SELCO**



Typical setup for application with dependable DC supply source.




# D1000 Supply

Module driven by AC with battery back-up

Trip Coil driven by battery back-up

**SELCO**




Typical setup for application powered by AC, where AC supply can fail. 24 VDC chargeable lead battery provides backup supply for module and Trip Coil. D1000 consumes approximately 1.5 watts on battery. Battery time will depend on battery capacity.

# D1000 Supply

## Module driven by AC and DC

### Trip Coil driven by external voltage

**SELCO**




Typical setup for application power by AC, where AC supply can fail.

DC supply provides back-up for module.

Trip coil driven by external DC or AC voltage (note that AC trips are a bit slower than DC – because of the AC voltage period time).

# D1000 Supply Module and Trip Coil driven by AC Supply

**SELCO**



Typical setup for application with dependable AC supply source.

(Not recommended due to the extra delay from the AC period – if possible, use a backup battery and a 24VDC trip coil)

# Logging and Diagnostics

# SELCO

## Log with Date and Time

- Event log with date and time
- Performance graphs

